

Lumen T2 Label Printer

Quick Start Guide

Contents

What's in the box	2
Setting up	2
Printing your first label	3
Specifications	4
Status light	5

What's in the box

- ☒ Lumen T2 printer
- ☒ USB-C cable (1 m)
- ☒ Power adapter, 24 V
- ☒ One roll of 50 × 30 mm labels

Warning

Use only the power adapter supplied with the printer.
Other adapters can damage the print head.

Setting up

1. Open the top cover by pressing the release button on the right side.
2. Load the label roll with the labels facing up, and pull about 5 cm through the slot.
3. Close the cover until it clicks. The printer feeds one label to find the gap.
4. Connect the power adapter and press the power button for two seconds.




Figure 1 The status light during setup

Printing your first label

Install the Lumen app, then add the printer:

Settings → Printers → Add → Lumen T2

Tip

Hold the feed button for three seconds to print a test label with the printer's settings.

Specifications

Table 1 Lumen T2 specifications

Item	Value
Print method	Direct thermal
Resolution	300 dpi
Print speed	up to 150 mm/s
Label width	20–60 mm
Connection	USB-C, Wi-Fi 2.4 GHz
Size	118 × 96 × 82 mm

Status light

Light	Meaning	What to do
Green	Ready	—
Blinking green	Printing	Wait
Orange	Out of labels or cover open	Load labels, close the cover
Red	Print head too hot	Pause for five minutes